


CHOKE LEVER AND HIGH ALTITUDE COMPENSATOR KNOB

The choke lever ① and a high altitude compensator knob ② are located on the left side of the carburetor.

Raising the choke lever will close the choke valve. With the choke lever raised, the carburetor will deliver a rich fuel mixture for starting the engine when cold. Lower the choke lever as the engine attains normal operating temperature.

The carburetor is equipped with an altitude compensator to provide leaner fuel mixture needed in high altitude operation.

Pull the compensator knob out when riding at altitudes above 6000 feet. The knob must be pushed in when riding at altitudes below 6000 feet.



① Choke lever



② High altitude compensator knob