


Oil filter screen cleaning:

1. Drain the engine thoroughly. (See page 44.)
2. Remove the kick starter pedal, muffler and right crankcase cover.
3. Remove the oil filter screen (1) and wash it in clean solvent.
4. Reinstall the filter screen, right crankcase cover, muffler and kick starter pedal.
5. Fill the crankcase with new engine oil. (See page 44.)



Limpieza de la malla del filtro:

1. Drene completamente el motor. (véase la página 44.)
2. Remueva el pedal del arranque de pie, silenciador y cubierta de la caja de cigüeñal derecha.
3. Remueva la malla del filtro de aceite (1) y lávela en una solución limpia.
4. Remonte la malla del filtro, caja del cigüeñal derecha, silenciador y pedal del arranque de pie, en este orden.
5. Rellene la caja de cigüeñal con el nuevo aceite para motor. (véase la página 44.)