

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING								NOTE (1)
			x 1,000 km	1	6	12	18	24	30	36	REFER TO PAGE
			x 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
DRIVE CHAIN			EVERY 1,000km (600mi) I, L								66
DRIVE CHAIN SLIDER					I			I		I	71
BRAKE FLUID		(NOTE 4)		I	I	R	I	I	R		15
BRAKE PADS WEAR				I	I	I	I	I	I		79
BRAKE SYSTEM			I		I		I		I		15, 79
* BRAKE LIGHT SWITCH					I		I		I		89
* HEADLIGHT AIM					I		I		I		—
CLUTCH SYSTEM					I		I		I		19
CLUTCH FLUID		(NOTE 4)		I	I	R	I	I	R		19
SIDE STAND					I		I		I		72
* SUSPENSION					I		I		I		—
* NUTS, BOLTS, FASTENERS			I		I		I		I		—
** WHEELS / TYRES					I		I		I		—
** STEERING HEAD BEARINGS			I		I		I		I		—