



MAINTENANCE

page

63 MAINTENANCE

63	THE IMPORTANCE OF MAINTENANCE
64	MAINTENANCE SAFETY
65	SAFETY PRECAUTIONS
66	MAINTENANCE SCHEDULE
69	TOOL KIT
70	SERIAL NUMBERS
71	COLOUR LABEL
72	CRANKCASE BREATHER
73	ENGINE OIL
77	SPARK PLUG
79	VALVE CLEARANCE
82	THROTTLE OPERATION
83	IDLE SPEED
84	DRIVE CHAIN
91	FRONT AND REAR SUSPENSION INSPECTION
92	SIDE STAND
93	WHEEL REMOVAL
99	BRAKE PAD WEAR
100	BRAKE SHOE WEAR
101	BATTERY

page

103	FUSE REPLACEMENT
107	BRAKELIGHT SWITCH ADJUSTMENT
108	BULB REPLACEMENT

114 CLEANING

118 STORAGE GUIDE

118	STORAGE
120	REMOVAL FROM STORAGE

121 TAKING CARE OF THE UNEXPECTED

122 SPECIFICATIONS

126 CATALYTIC CONVERTERS (TU, IITU)

