
## (Type I)

Brakes are items of personal safety and should always be maintained in proper adjustment.

The distance the front brake lever (1) moves before the brake starts to engage is called freeplay.

Measured at the tip of the front brake lever, freeplay should be maintained at: 10-20 mm (0.4-0.8 in)

Adjust the freeplay of the brake lever with the front wheel pointed straight ahead.



(1) Front brake lever

23

