

(Ref.No.) Description	Function
(1) Tripmeter	Shows mileage per trip.
(2) Speedometer	Shows riding speed.
(3) Odometer	Shows accumulated mileage.
(4) Tachometer	Shows engine rpm.
(5) Tachometer red zone	<p>Never allow the tachometer needle to enter the red zone, even after the engine has been broken in.</p> <p><b>CAUTION:</b>  <b>* Running the engine beyond recommended maximum engine speed (the beginning of the tachometer red zone) can damage the engine.</b></p>
(6) Coolant temperature gauge	Shows coolant temperature(see page12 ).