In addition, to move the ordinary display at display setting.

- The button is not pressed for about 30 seconds.
- Turn the ignition switch off and then on.

## 1 Time format setting:

You can switch the time format between 12 hour format or 24 hour format.

- 1 Turn the ignition switch to ON.
- 2 Press and hold the SEL button and the SET button, the current time format and the clock start flashing.



3 Press the SEL button to select "12hr" or "24hr".



4 Press the **SET** button. The time format is set, and then the display moves to the clock setting.