

Cold Engine Starting Procedure . . . . .	25
Starting in Extremely Cold Weather . . . . .	27
Warm Engine Starting Procedure . . . . .	27
<b>BREAK-IN PROCEDURE . . . . .</b>	<b>28</b>
<b>RIDING THE MOTORCYCLE . . . . .</b>	<b>29</b>
<b>SAFE RIDING SUGGESTIONS . . . . .</b>	<b>32</b>
<b>LOADING AND ACCESSORIES . . . . .</b>	<b>33</b>
<b>PARKING . . . . .</b>	<b>34</b>
<b>TOOL KIT . . . . .</b>	<b>35</b>
<b>MAINTENANCE SCHEDULE . . . . .</b>	<b>36</b>
<b>MAINTENANCE OPERATIONS . . . . .</b>	<b>39</b>
Engine Oil Level Check . . . . .	39
Engine Oil . . . . .	39
Spark Plug Replacement and Adjustment . . . . .	43
Ignition timing Adjustment . . . . .	44
Valve Tappet Clearance Adjustment . . . . .	47
Cam Chain Adjustment . . . . .	50
Air Cleaner Maintenance . . . . .	51
Throttle Cable Inspection . . . . .	54
Throttle Grip Play Adjustment . . . . .	55
Carburetor Adjustment . . . . .	56
Fuel Filter Maintenance . . . . .	57