

# CONTENTS

<b>GENERAL DESCRIPTION</b> .....	5
■ <b>SERIAL NUMBER LOCATION</b> .....	5
■ <b>NOMENCLATURE</b> .....	6
<b>OPERATING INSTRUCTIONS</b> .....	9
■ <b>INSTRUMENTS AND INDICATOR LAMPS</b> .....	9
■ <b>ELECTRICAL CONTROLS</b> .....	12
● Main Key Switch .....	12
● Ignition Switch .....	13
● Starter Switch .....	13
● Headlight (Control) Switch .....	13
● Turn Signal (Control) Switch .....	14
● Horn Button .....	14
● Stop Light Switches .....	14
■ <b>MECHANICAL CONTROLS</b> .....	15
● Steering Lock .....	15
● Seat Lock .....	15
● Helmet Holder .....	16
● Front Brake (Control) Lever .....	16
● Throttle (Control) Grip .....	17
● Rear Brake (Control) Pedal .....	18
● Clutch (Control) Lever .....	18