

FREQUENCY		WHICHEVER COMES FIRST ↓	ODOMETER READING [NOTE(4)]							Refer to
			600 mi (1,000 km)	4,000 mi (6,400 km)	8,000 mi (12,800 km)	12,000 mi (19,200 km)	16,000 mi (25,600 km)	20,000 mi (32,000 km)	24,000 mi (38,400 km)	
ITEMS		EVERY								
NON-EMISSION RELATED ITEMS	* FINAL DRIVE OIL				I		I		R	Page 57
	BATTERY	MONTH	I	I	I	I	I	I	I	Pages 66—67
	BRAKE FLUID (FRONT)	MONTH I 2 YEARS *R	I	I	I	*R	I	I	*R	Pages 18—19
	BRAKE SHOE/PAD WEAR			I	I	I	I	I	I	Page 64
	BRAKE SYSTEM		I	I	I	I	I	I	I	Pages 18—20
	* BRAKE LIGHT SWITCH		I	I	I	I	I	I	I	
	* HEADLIGHT AIM		I	I	I	I	I	I	I	
	CLUTCH FLUID	MONTH I 2 YEARS *R	I	I	I	*R	I	I	*R	Page 21
	CLUTCH SYSTEM		I	I	I	I	I	I	I	Page 21
	SIDE STAND			I	I	I	I	I	I	Page 65
	* SUSPENSION		I	I	I	I	I	I	I	
	* NUTS, BOLTS, FASTENERS		I	I	I	I	I	I	I	
	** WHEELS		I	I	I	I	I	I	I	
** STEERING HEAD BEARING		I		I		I		I		

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.

* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SHOP MANUAL.

- NOTES: (1) Service more frequently when riding in dusty areas.
 (2) Service more frequently when riding in rain, or at full throttle.
 (3) California type only.
 (4) For higher odometer reading, repeat at the frequency interval established here.