


The engine number (3) is stamped on top of the crankcase.

ENGINE NO. \_\_\_\_\_




(3) Engine number

## COLOR LABEL

The color label (4) is attached to the down tube under the right side cover. It is helpful when ordering replacement parts. Record the color here for your reference.

COLOR \_\_\_\_\_



(4) Color label