


## Odometer/Tripmeter Display

The display (1) has two functions, odometer and tripmeter.

Push the button (2) to select “ODO” or “TRIP” mode.

To reset the tripmeter, push and hold the button when the display is in the “TRIP” mode.



(1) Odometer/Tripmeter display

(2) Odometer/Tripmeter select and reset button

Odometer

Tripmeter

Tripmeter  
reset

