

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	83	
* CHOKE OPERATION					I		I		I	—	
AIR CLEANER		NOTE (2)					C		C	85	
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	79	
SPARK PLUG					I		R		I	80	
* VALVE CLEARANCE							I			—	
ENGINE OIL				R		R		R	R	75	
ENGINE OIL FILTER				R		R		R	R	76	
* ENGINE IDLE SPEED				I	I	I	I	I	I	84	
RADIATOR COOLANT		NOTE (4)				I		I	R	25	
* COOLING SYSTEM						I		I	I	—	
* SECONDARY AIR SUPPLY SYSTEM						I		I	I	—	