

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
* FUEL LINE					I			I		I	—
* THROTTLE OPERATION						I		I		I	93
* CHOKE OPERATION						I		I		I	—
AIR CLEANER	NOTE (2)						C			C	95
CRANKCASE BREATHER	NOTE (3)				C	C	C	C	C	C	89
SPARK PLUGS						I		R		I	90
* VALVE CLEARANCE								I			—
ENGINE OIL			R			R		R		R	83
ENGINE OIL FILTER			R			R		R		R	86
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	I	94
RADIATOR COOLANT	NOTE (4)					I		I		R	32
* COOLING SYSTEM						I		I		I	—
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—