


HEADLIGHT AIM VERTICAL ADJUSTMENT

Vertical adjustment is possible by turning the knob (2) to move it up or down in accordance with requirements. Obey local laws and regulations.



- | | |
|--------------------|----------|
| (1) Headlight case | (A) Down |
| (2) Knob | (B) Up |