03/10/23 11:14:51 32KPF600 080

## FRONT AND REAR SUSPENSION INSPECTION

(Refer to the maintenance precautions on page 57).

- Check the fork assembly by locking the front brake and pumping the fork up and down vigorously. Suspension action should be smooth and there must be no oil leakage.
- 2. Swingarm bearings should be checked by pushing hard against the side of the rear wheel while the motorcycle is on a support block. Free play indicates worn bearings.
- 3. Carefully inspect all front and rear suspension fasteners for tightness.

