

<b>(Ref. Nr.) Description</b>	<b>Function</b>
(8) Left turn signal indicator (green)	Flashes when the left turn signal operates.
(9) Anti-lock brake system (ABS) indicator light (red)(CBF500A)	This indicator light normally illuminates when the ignition switch is set to ON and is extinguished when the motorcycle is ridden at a speed of more than 10 km/h (6mph). If there is a problem with the ABS system, this light flashes and remains on (see page 18)
(10) Odometer digital display	<p>This display shows the following information:</p> <p><b>main odometer:</b> total distance travelled by the motorcycle;</p> <p><b>trip odometer:</b> resettable distance of individual journeys.</p> <p>There are two trip odometers, trip odometers 1 and 2. You can switch between the display of trip odometer 1 and 2 by repeatedly pressing the right control key (7). To reset the trip odometer, hold down the reset odometer key (11) while displaying trip odometer 1 or trip odometer 2 for two seconds.</p>