STORAGE GUIDE

Extended storage, such as for winter requires that you take certain steps to reduce the effects of deterioration from non-use of the motorcycle. In addition, necessary repairs should be made BEFORE storing the motorcycle - otherwise, these repairs may be forgotten by the time the motorcycle is removed from storage.

STORAGE

- 1. Change the engine oil and filter.
- 2. Make sure the cooling system is filled with a 50/50% antifreeze solution.
- Empty the fuel tank into an approved petrol container using a commercially available hand siphon or an equivalent method. Spray the inside of the tank with an aerosol rust-inhibiting oil.

Reinstall the fuel fill cap on the tank.

If storage will last more than one month, carburetor draining is very important, to assure proper performance after storage

A WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Refuel only outdoors.
- Wipe up spills immediately.