


Battery Care

Inspecting and topping up the electrolyte level should be performed frequently as indicated in the Maintenance Schedule (page 104) and Pre-riding Inspection (page 84).

The battery (1) is under the seat. Unhook the strap (2) and remove the battery cover (3). Remove the tool kit and pull back the separator (4). Check the electrolyte level.

The electrolyte level must be maintained between the upper (5) and lower (6) level marks on the side of the battery. If the electrolyte level is low remove the filler cap (7) from each battery cell.



Soin de la batterie

L'inspection et l'appoint du niveau d'électrolyte doivent être effectués fréquemment comme indiqué dans le programme d'entretien (page 100) et l'inspection avant conduite (page 106).

La batterie (1) se trouve sous la selle. Décrocher la bande (2) et retirer le couvercle de la batterie (3). Déposer la trousse à outils et décrocher le séparateur (4).

Vérifier le niveau de l'électrolyte.

Le niveau de l'électrolyte doit être maintenu entre les repères de niveau supérieur (5) et inférieur (6) sur le côté de la batterie. Si le niveau de l'électrolyte est bas, retirer le bouchon de remplissage (7) de chaque élément de batterie.

