

MAINTENANCE SCHEDULE

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult your authorized Honda Dealer.

Perform the Pre-ride Inspection (page 40) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM		FREQUENCY	WHICHEVER →		ODOMETER READING [NOTE(1)]							
			COMES FIRST ↓	x1,000km	1	6	12	18	24	30	36	REFER TO PAGE
		NOTE	x1,000mi	0.6	4	8	12	16	20	24		
MONTH		6	12	18	24	30	36					
*	FUEL LINE						I		I		I	—
*	THROTTLE OPERATION						I		I		I	64
*	CARBURETOR CHOKE						I		I		I	—
	AIR CLEANER	(NOTE 2)							R		R	56
	CRANKCASE BREATHER	(NOTE 3)				C	C	C	C	C	C	57
	SPARK PLUG					I	R	I	R	I	R	61-63
*	VALVE CLEARANCE			I		I		I		I		—
	ENGINE OIL			R		R		R		R		58-61
	ENGINE OIL FILTER			R		R		R		R		59-61
*	CARBURETOR SYNCHRONIZATION					I		I		I		—
*	CARBURETOR IDLE SPEED			I	I	I	I	I	I	I	I	65
	RADIATOR COOLANT	(NOTE 4)				I		I		R		23-24
*	COOLING SYSTEM					I		I		I		—
*	SECONDARY AIR SUPPLY SYSTEM	(NOTE 5)				I		I		I		—