## OPERATION PRE-RIDE INSPECTION

## **AWARNING**

\* If the Pre-ride Inspection is not performed, severe personal injury or vehicle damage may result.

Inspect your motorcycle every day before you ride it. The items listed here will only take a few minutes to inspect, and in the long run they can save time, expense, and possibly your life.

- 1. Engine oil level—add engine oil if required (page 28). Check for leaks.
- 2. Fuel level-fill fuel tank when necessary (page 26). Check for leaks.
- 3. Coolant level—add coolant if required. Check for leaks (pages 22 23).
- 4. Front and rear brakes—check operation; make sure there is no brake fluid leakage (pages 17 20).

- 5. Tyres—check condition and pressure (page 29-31).
- Drive chain—check condition and slack (page 72). Adjust and lubricate if necessary.
- 7. Throttle—check for smooth opening and full closing in all steering positions
- 8. Lights and horn—check that headlight, tail/brake light, turn signals, indicators and horn function properly.
- 9. Engine stop switch—check for proper function (page 33).
- 10. Side stand ignition cut-off system—check for proper function (page 78).
- 11. Battery electrolyte—check the level and add if necessary (page 90).

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.