

FREQUENCY		WHICHEVER →		ODOMETER READING [NOTE(1)]								REFER TO PAGE
		COMES FIRST ↓	x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
ITEM		NOTE	MONTH		6	12	18	24	30	36		
	DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)								74-78
	DRIVE CHAIN SLIDER				I			I		I	79	
	BATTERY				I	I	I	I	I	I	92-94	
	BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R	17-20	
	BRAKE PAD WEAR				I	I	I	I	I	I	89	
	BRAKE SYSTEM			I		I		I		I	17-20, 91	
*	BRAKE LIGHT SWITCH					I		I		I	97	
*	HEADLIGHT AIM					I		I		I	-	
	CLUTCH SYSTEM					I		I		I	21	
	CLUTCH FLUID	(NOTE 4)			I	I	R	I	I	R	21	
	SIDE STAND					I		I		I	80	
*	SUSPENSION					I		I		I	79	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	-	
**	WHEELS/TYRES					I		I		I	-	
**	STEERING HEAD BEARINGS			I		I		I		I	-	