

<b>(Ref.No.) Description</b>	<b>Function</b>
(5) HISS button	This button is used to flash the immobilizer system (HISS) indicator when the ignition switch is OFF (page 47 ).
(6) Immobilizer system (HISS) indicator (red)	This indicator lights for a few seconds when the ignition switch is turned ON and the engine stop switch is at $\odot$ (RUN). It will then go off if the properly-coded key has been inserted. If an improperly-coded key has been inserted, the indicator will remain on and the engine will not start (page 46 ).
(7) MODE button	Select tripmeter A or B and resets the tripmeter to zero (0) (page 20 ). This button is also used to change unit of speedometer (page 21 ).
(8) SET button	This button is used to adjust the time (page 22 ). This button is also used to change unit of speedometer (page 21 ).