

GENERAL INFORMATION

FRAME	LOCATION	MATERIAL	REMARKS
	Steering head bearing sliding surface Steering head bearing dust seal lips Front fork oil seal lips Front wheel dust seal lips Rear wheel dust seal lips Rear wheel hub O-ring Clutch lever pivot bolt sliding surface Speedometer gear and pinion gear teeth Speedometer gear/pinion sliding surface Side stand pivot surface Throttle grip sliding surface Speedometer outer cable inside Seat lock sliding surface Brake pad pin sliding surface	Multi-purpose grease	
	Brake caliper pin bolt Brake lever pivot bolt sliding surface Brake lever-to-master piston contacting area Rear brake master piston-to-push rod contacting area Throttle cable inside	Silicone grease	
	Clutch inner cable surface Choke inner cable surface	Molybdenum compound oil	
	Fork socket bolt threads Cooling fan motor shaft threads	Locking agent	
	Handle grip rubber inside	Honda Bond A or equivalent	
	Brake master piston and cups Brake caliper piston and piston seals Brake caliper dust seal	DOT 3 or 4 brake fluid	
	Fork inside	Honda Ultra Cushion Oil No.10	
	Air cleaner housing tube joint	Sealant	