

# TROUBLESHOOTING

Starter motor will not turn

- Check for a blown main fuse (20A) or sub-fuse (10A).
- Check that the battery is fully charged and in good condition (section 17).

