


(Ref.No.) Description	Function
(4) Immobilizer system (HISS) indicator (green)	This indicator lights for a few seconds when the ignition switch is turned ON and the engine stop switch is at  (RUN). It will then go off if the properly-coded key has been inserted. If an improperly-coded key has been inserted, the indicator will remain on and the engine will not start (page 49).
(5) Coolant temperature meter	Shows coolant temperature (page 27). This meter shows the initial display (page 18).