

5. Tyres—check condition and pressure (pages 40 – 45 ).
6. Drive chain—check condition and slack (page 97 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions.
8. Lights and horn—check that headlight, brake/taillight, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 51 ).
10. Side stand ignition cut-off system—check for proper function (page 105 ).