

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓	ODOMETER READING [NOTE (1)]								Refer to
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH								
DRIVE CHAIN			I, L EVERY 1,000km (600mi)								Pages 72–76
DRIVE CHAIN SLIDER					I			I		I	Page 77
BRAKE FLUID		NOTE (3)			I	I	R	I	I	R	Pages 18–21
BRAKE PAD WEAR					I	I	I	I	I	I	Page 87
BRAKE SYSTEM				I		I		I		I	Pages 18–21
* BRAKE LIGHT SWITCH						I		I		I	–
* HEADLIGHT AIM						I		I		I	–
CLUTCH SYSTEM				I	I	I	I	I	I	I	Pages 22–23
SIDE STAND						I		I		I	Page 79
* SUSPENSION						I		I		I	Page 78
* NUTS, BOLTS, FASTENERS				I		I		I		I	–
** WHEELS/TYRES						I		I		I	–
** STEERING HEAD BEARINGS				I		I		I		I	–