

If the feeler gauge cannot be inserted easily, pull the left fork outward or push inward adjust the clearance. Then tighten the axle pinch bolt to the specified torque.

After installing the wheel, apply the brakes several times, then recheck both discs for caliper holder to disc clearance. Do not operate the motorcycle without adequate clearance.

▲WARNING

*** Failure to provide adequate disc to caliper holder clearance may damage the brake discs and impair braking efficiency.**