



The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:  
Current instant fuel mileage. If your speed is less than 7 km/h (5 mph), " --- " is displayed. When " --- " is displayed at speeds above 7 km/h (5 mph), go to your dealer for service.
  - Average fuel mileage:  
Average fuel mileage since tripmeter A was reset. When " --- " is displayed, go to your dealer for service.
  - Fuel consumption:  
Total fuel consumption since tripmeter A was reset. When " --- " is displayed, go to your dealer for service.
  - Reserve fuel consumption:  
If the engine stop switch is in the  (Off) position, " --- " is displayed. when " --- " is displayed in other cases, go to your dealer for service.
- ▶ **To reset the average fuel mileage and fuel consumption:**  **P.24**

continued 23