In addition, to move the ordinary display at display setting.

• The button is not pressed for about 30 seconds.
• Turn the ignition switch off and then on.

1 Time format setting:

You can switch the time format between 12 hour format or 24 hour format.

❶ Turn the ignition switch to ON.

❷ Press and hold ⌑SEL⌑ button and ⌑SET⌑ button, the current time format and the clock start flashing.

❸ Press ⌑SEL⌑ button to select "12hr" or "24hr".

❹ Press ⌑SET⌑ button. The time format is set, and then the display moves to the clock adjustment.

2 Clock setting:

❶ Press ⌑SEL⌑ button until the desired hour is displayed.

▶ Press and hold to advance the hour fast.

❷ Press ⌑SET⌑ button. The minute digits start flashing.

Operation Guide