

INSTRUMENTS AND INDICATORS

The indicators and warning lights are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Odometer
- (3) Oil pressure warning light
- (4) Turn signal indicator
- (5) Tachometer
- (6) Tachometer red zone
- (7) Coolant temperature gauge
- (8) Side stand indicator
- (9) High beam indicator
- (10) Neutral indicator
- (11) Tripmeter
- (12) Tripmeter reset knob

