


HEADLIGHT BEAM ADJUSTMENT

To adjust the headlightbeam vertically,
turn the screw (1), and knob (2) in either
direction.

Obey local laws and regulations.

▲ WARNING

* **Do not adjust the headlight beam while riding the motorcycle. Operating the motorcycle with one or both hands away from the handlebar/controls may result in a loss of vehicle control.**



(1) Screw
(A) Right
(B) Left

(2) Knob
(C) Up
(D) Down