

Stop/Taillight Bulb

▲WARNING

- * **The light bulb becomes very hot while the light is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.**


CAUTION:

- * **Wear clean gloves while replacing the bulb.**
- * **If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.**

NOTE:

- * **Be sure to turn the ignition switch OFF when replacing the bulb.**

1. Open the rear seat (page 41).
2. Turn the socket (1) 90° counter-clockwise, then pull it out toward you.



(1) Socket