

## Speedometer/Odometer/Tripmeter

### Speedometer

Shows riding speed.

### Odometer



Shows accumulated mileage.

### Tripmeter

Shows mileage per trip.

There are two tripmeters, tripmeter A (5) and tripmeter B (6). Switch between the A and B displays by pressing the left control button (4) repeatedly.

To reset the tripmeter, push and hold the left control button with the display in the tripmeter A or tripmeter B mode.



- |                 |                         |
|-----------------|-------------------------|
| (1) Speedometer | (4) Left control button |
| (2) Odometer    | (5) Tripmeter A         |
| (3) Tripmeter   | (6) Tripmeter B         |