


Speed Unit Change

(E type only)

The speedometer displays both “km/h” and “mph”.

Push the right control button (7) to select “km/h” or “mph”.



(7) Right control button