


## Anti-theft Locking Cable

The anti-theft locking cable is stored in the left fairing pocket. This cable is used when the motorcycle is parked for preventing from theft of the motorcycle.

1. Insert the ignition key into the helmet holder (1) and turn it counterclockwise to unlock (See page 86).
2. Untie the cable and secure the cable to the post or picket, etc., at the loop side.
3. Hang your helmet on the chain on the cable, insert the chain through the locking piece (2), and install the locking piece to the helmet holder pin. Push in the holder pin.



## Cable de bloqueo antirobo

La cadena antirrobo está guardada en la bolsa del carenado izquierdo. Este cable se utiliza cuando la moto está aparcada como prevención contra robo de la moto..

1. Introduzca la llave de encendido en el soporte del casco (1) y gírela hacia la izquierda para abrir (ver la página 86).
2. Desate el cable y fíjelo en la barra o piquete, etc. del lado de la anilla.
3. Cuelgue su casco en la cadena del cable, inserte la cadena a través de la pieza de bloqueo (2), e instále esta pieza de bloqueo en el pasador del soporte del casco. Presione hacia adentro el pasador del soporte.