

Patrol Switch (Patrol light, Meter stop, Siren)

The patrol switch (1) is located at the right handlegrip bracket.

This switch can be operated when the ignition switch is set to the "ON" position.

• (OFF) . . .The patrol light, meter stop, and siren are not operated.

PThe patrol light is on.

When the patrol light is flashing, the flasher switch on the left handlebar must be when released the patrol switch.
(See page 78.)

MThe patrol light is lit (or flashing) and the pointer of the meter is stopped to detect the speed.

SThe siren is sounded. The patrol light and meter stop operating. Since the "S" position employs an automatic return pushed. It is necessary to keep the button pushing to sound the siren continuously.

NOTE: All the electrical circuits are open and the pointer of the police meter returns to the "O" position when the ignition switch is turned "OFF". Note that the pointer of the meter also returns to the "O" position even if the patrol switch is set to the "P" or "•" position.

