


Tool Kit

The tool kit (3) is in the storage compartment behind the left side cover. To open the storage compartment cover (2), insert and turn the key (1) counterclockwise. Some roadside repairs, minor adjustments

- 8 mm open end wrench
- 10 x 12 mm open end wrench
- 14 x 17 mm open end wrench
- Pliers
- No. 4 Screw driver
- No. 2 Plus minus driver
- Screwdriver grip
- 12 mm box end wrench
- 27 mm box end wrench
- 10 x 12 mm box end wrench
- Spark plug wrench
- Feeler gauge 0.7 mm
- Tool bag
- Pin spanner
- 5 mm hex. wrench
- 6 mm hex. wrench



Trousse à outils

La trousse à outils (3) se trouve à l'intérieur du compartiment de rangement derrière le cache latéral gauche. Pour ouvrir le couvercle du compartiment (2), introduire la clé de contact (1) dans la serrure et la tourner dans le sens inverse des aiguilles d'une montre. Certains petits réglages et remplacements de pièces de première urgence peuvent être effectués avec les outils de cette trousse.

- Clé à fourches de 8 mm
- Clé à fourches de 10 x 12 mm
- Clé à fourches de 14 x 17 mm
- Pincettes
- Tournevis N° 4
- Tournevis plus minus N° 2
- Poignée de tournevis
- Clé à douille de 12 mm
- Clé à douille de 27 mm
- Clé à douille de 10 x 12 mm
- Clé à bougie
- Calibre d'épaisseur de 0,7 mm
- Trousse à outils
- Clé pour goupille
- Clé Allen de 5 mm
- Clé Allen de 6 mm

