

MAINTENANCE

Page		Page	
51	MAINTENANCE	77	Brake Pad Wear
52	Maintenance Schedule	78	Brake Shoe Wear
54	Tool Kit	79	Battery
55	Serial Numbers	81	Fuse Replacement
56	Maintenance Precautions	84	Stoplight Switch Adjustment
57	Air Cleaner		
58	Crankcase Breather	85	CLEANING
59	Engine Oil		
62	Spark Plugs	86	STORAGE GUIDE
65	Final Drive Oil	86	Storage
66	Throttle Operation	87	Removal from Storage
67	Idle Speed		
68	Front and Rear Suspension Inspection	88	SPECIFICATIONS
68	Side Stand		
69	Wheel Removal		