

MAJOR COMPONENTS (Information you need to operate this motorcycle)

▲ WARNING

- * If the Pre-ride Inspection (page 44) is not performed, severe personal injury or vehicle damage may result.


ANTI-DIVE ADJUSTER

This adjuster (1) reduces nose-dive during braking and may be adjusted to the rider's choice independent of load or the rider's weight. Located on the left side of the front fork, this adjuster can be set to any one of four positions.

Position	Anti-dive damper force
1	LIGHT ANTI-DIVE
2	MEDIUM
3	HARD
4	MAXIMUM ANTI-DIVE

▲ WARNING

- * Do not position the adjuster between the numbered detent adjustment points.



(1) Anti-dive adjuster