


The volume can be adjusted with the volume control knob (7) at the rear of the amplifier.


NOTE:

- * When removing the microphone, hold the microphone jack. Do not remove by pulling on the cord. (See the illustration)



(7) Volume control knob

NOT GOOD



GOOD

