


- Remove the fuel fill cap (4) by turning it counterclockwise.
- Add fuel until the level reaches the bottom of the filler neck (5). Avoid overfilling the tank. There should be no fuel in the filler neck.



(5) filler neck

⚠ WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
 - Handle fuel only outdoors.
 - Wipe up spills immediately.
- After refueling, install the fuel fill cap by turning it clockwise.
 - Turn the ignition key counterclockwise and remove it.
 - Close the fuel tank lid.