

manuals	188
warranty	192
spark knock	87
spark plug.....	111
specifications	169
speedometer	19
start button	22
starting,	
engine.....	45
troubleshooting	147
steering lock.....	61
stop switch, engine	22
stopping engine.....	50
storage,	
owner's manual	84
scooter.....	138
switch,	
engine stop.....	22
headlight dimmer.....	23
ignition.....	20

turn signal	23
-------------------	----

T

temperature indicator, coolant.....	19
theft prevention tips.....	63
throttle.....	107
tires,	
air pressure.....	118
flat.....	152
replacing	122
training, rider	3, 32
transporting your scooter.....	142
trouble, unexpected	145
troubleshooting, starting.....	147
turn signal indicator.....	19