## **Maintenance Schedule**

		Frequency		Whichever Comes First		Initial Regular Maint. Interva				al Refer
		⇒	mi	100	600	1,200	1,800	2,400	to page:	
Items				km	150	1,000	2,000	3,000		4,000
_	т т		Note	Month	11	6	12	18	24	1 6-
EMISSION REL	*	Fuel Line					I		Ī	
	* *	Fuel Strainer Screen					C		Ċ	
SIC	*	Throttle Operation					ī		ī	68
×		Air Cleaner	Note 1			C	C	С	C	65
Æ		Spark Plug				Ī	ī	ī		75
ATED ITEMS	*	Valve Clearance			I	ì			T	
		Engine Oil			R	R	R	R	R	59
	* *	Engine Oil Strainer Screen			_ ``		C		$\frac{1}{C}$	
	*	Cam Chain Tension			A	A	A	A		
	* *	Engine Idle Speed			I	I	I	I	A	74

<sup>\*</sup> Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 144).

<sup>\*\*</sup> In the interest of safety, we recommend these items be serviced only by your Honda dealer.