



Maintenance Schedule

Items	Frequency	Whichever Comes First ⇔	Initial Maint.	Regular Maint. Interval					Refer to page:
			mi	600	1,200	1,800	2,400		
			km	1,000	2,000	3,000	4,000		
Note	Month	1	6	12	18	24			
* Fuel Line					I		I	—	
* Throttle Operation					I		I	73	
Air Cleaner		Note 1		C	C	C	C	69	
Crankcase Breather				I	I	I	I	72	
Spark Plug				I	I	I	I	82	
* Valve Clearance			I	I	I	I	I	78	
Engine Oil			R	R	R	R	R	63	
** Engine Oil Strainer Screen					C		C	—	
** Engine Oil Centrifugal Filter					C		C	—	
** Engine Idle Speed			I	I	I	I	I	81	

* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 160).

**In the interest of safety, we recommend these items be serviced only by your dealer.

