

# Maintenance Schedule

## MAINTENANCE SCHEDULE – REGULAR OFF-ROAD USE (NON-COMPETITION)

ITEMS	FREQUENCY	Which ever Comes First ⇒	Initial Maint	Regular Maintenance Interval				Refer to Page:		
				mi	100	600	1,200		1,800	2,400
				km	150	1,000	2,000		3,000	4,000
NOTE	Month	1	6	12	18	24				
* FUEL LINE					I		I	41		
** FUEL STRAINER SCREEN					C		C	42		
* THROTTLE OPERATION					I		I	55		
AIR CLEANER	(NOTE 1)			C	C	C	C	51		
CRANKCASE BREATHER				I	I	I	I	53		
SPARK PLUG				I	I	I	I	61		
* VALVE CLEARANCE			I	I	I	I	I	66		
ENGINE OIL			R	R	R	R	R	43		
ENGINE OIL FILTER			R	R	R	R	R	44		
* DECOMPRESSOR SYSTEM			I	I	I	I	I	–		
** ENGINE IDLE SPEED			I	I	I	I	I	140		
RADIATOR COOLANT	(NOTE 3)				I		R	48		
* COOLING SYSTEM			I	I	I	I	I	49		
* SECONDARY AIR SUPPLY SYSTEM	(NOTE 2)				I		I	–		
TRANSMISSION OIL			R	R	R	R	R	46		
DRIVE CHAIN	(NOTE 1)		I, L	I, L: every 300 mi (500 km) or 3 months				96 – 98		
DRIVE CHAIN SLIDER				I	I	I	I	98		
BRAKE FLUID	(NOTE 3)			I	I	I	I	89		
BRAKE PADS WEAR				I	I	I	I	91		
BRAKE SYSTEM			I	I	I	I	I	88		
* HEADLIGHT AIM					I		I	107		
CLUTCH SYSTEM			I	I	I	I	I	56		
SIDE STAND					I		I	95		
* SUSPENSION					I		I	84, 85		
* SPARK ARRESTER				C: every 1,000 mi (1,600 km) or every 100 operating hours				65		
* NUTS, BOLTS, FASTENERS			I		I		I	103, 160 – 163		
** WHEELS/TIRES			I	I	I	I	I	92, 93		
** STEERING HEAD BEARINGS			I		I		I	102		

\* Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 174).

\*\* In the interest of safety, we recommend these items be serviced only by your Honda dealer.

Summary of Maintenance Schedule Notes and Procedures;

### NOTES:

1. Service more frequently when ridden in wet or dusty conditions.
2. USA and Canada type only.
3. Replace every 2 years. Replacement requires mechanical skill.