

# Fuel

---

3. After refueling, turn the fuel fill cap clockwise until it is secure.
4. Check that the breather tube is properly seated in the front number plate.

*If you replace the fuel fill cap, use only a genuine Honda replacement part.*