

REMOVAL FROM STORAGE

1. Uncover and clean the motorcycle.
Change the engine oil if more than 4 months have passed since the start of storage.
2. Perform all Pre-ride Inspection checks (page 35).
3. Test ride the motorcycle at low speeds in a safe riding area away from traffic.