

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]						
			× 1,000 km	1	4	8	12	Refer to pages	
			× 1,000 mi	0.6	2.5	5	7.5		
		MONTHS		6	12	18			
DRIVE CHAIN		NOTE (3)		EVERY 1,000 km (600 mi)	I	I	I	I	67-71
BATTERY		NOTE (5)				I	I	I	79-80
BRAKE SHOES WEAR						I	I	I	78
BRAKE SYSTEM					I	I	I	I	16-20
* BRAKE LIGHT SWITCH						I	I	I	84
* HEADLIGHT AIM						I	I	I	38
CLUTCH SYSTEM					I	I	I	I	21
SIDE STAND						I	I	I	73
* SUSPENSION						I	I	I	72
* NUTS, BOLTS, FASTENERS		NOTE (3)			I		I		-
** WHEELS/TYRES		NOTE (3)			I	I	I	I	-
** STEERING HEAD BEARINGS					I			I	-